

Subcontractor Requirements

- All subcontractors to be considered in working with Team-TSI must have a minimum of 2 years experience in the 12 volt industry
- MECP certified is a plus
- Car dealership expediting experience is a plus
- Must have thorough knowledge of automotive electronics
- Must be experienced in alarm and remote start installations
- Must have thorough knowledge of SPDT 12 volt relays
- Must have thorough knowledge of diodes and their use
- Must be able to properly use a DMM (Digital Multi-meter)
- Must have all necessary tools (tool list on next page)
- Must have thorough computer skills
- Must have valid driver's license
- Must have liability and garage keepers insurance and list Team TSI as an additional insured- \$500,000 minimum coverage
- Must have vehicle insurance coverage minimums and list Team TSI as an additional insured
 - \$100,000 bodily injury
 - \$300,000 per accident
 - \$50,000 property coverage
- Must be open and receptive to all guidance given by Team-TSI Subcontractor Management Team
- Must be able to provide at least 3 references to be considered
- Must take and successfully pass Team-TSI Subcontractor Certification Exam

Subcontractors to be considered will fall under one of three categories

1. 12 volt shops with a fixed location only
2. 12 volt shops with a fixed location as well as mobile service
3. Mobile service only

Required Tools List

- Portable tool box/bag
- Laptop or netbook for unit troubleshooting and testing
- Fax machine
- Email Address
- Digital camera
- Cordless drill, 2+ batteries, and charger
- Magnetic bit holder and assorted tips (Phillips, Torx, Security Torx, Allen, etc.)
- Awl /Pick tool
- Right angle driver (skewdriver)
- **RATCHETING CRIMPERS-THIS IS THE ONLY ACCEPTABLE TYPE**
- Assorted screwdrivers (Phillips #1,2 and 3, Flathead small and large)
- 1/4" and 3/8" ratchet
- Finger ratcheting wheel
- 30-40 piece socket set (SAE and metric)
- Wire cutters
- Flush cutters
- Uni-bit / Hole Saw
- Digital Multi-meter (**Test Probes are not permitted**)
- Assorted pliers
- Razor Knife
- Ford radio removal tool
- Headlamp/ Flash light
- Door panel removers
- Putty knife
- Butane soldering iron

All TSI subcontractors are to have ratcheting crimpers

NO Test Lights, Test Probes, Power Probes. NO EXCEPTIONS!!